



HYDRO ROYAL GEOTHERMAL HEAT PUMPS

Horizontal Units

Vertical Units




DISCHARGE OF
'LE' CONFIGURATION

DISCHARGE OF
'RE' CONFIGURATION

LEFT RETURN
FRONT WATER

LF

HP024H
& UP TO
HPx060H






DISCHARGE OF
'LE' CONFIGURATION

DISCHARGE OF
'RE' CONFIGURATION

LEFT RETURN
BOTTOM WATER

LB



HP012H
& UP TO
HP018H



HPX090H
& UP TO
HPX0120H

RIGHT RETURN
FRONT WATER

RF



HPX072H &
HPX144H

RIGHT RETURN
BOTTOM WATER

RB

